# Chinese Version



**NOBLE**

www.nobleaudio.com
https://www.facebook.com/NobleAudio
https://www.instagram.com/nobleaudio/
https://twitter.com/noblebywizard

图 217-241235

## FoKus Triumph
真无线立体声耳机
使用说明书

---

### 包装清单

充电盒 x1　　耳机　　USB充电线 x1

耳塞套 x6　　使用说明书 x1　　收纳袋 x1

01

### 外观图示

多功能传感器 (MFS)

复位键

麦克风

LED 指示灯

LED 指示灯

USB Type C 充电端口

02

---

### 充电

❶ 说明：首次使用前请确保耳机和充电盒已充满电。
充电前和充电过程中，耳机和充电盒需要保持干净和干燥。

充电步骤：
1. 耳机放回充电盒且关闭充电盒时会自动关机。
打开充电关闭充电盒盖子时，LED指示灯会显示充电状态。
2. 插入 USB Type C 充电线，将充电盒与电源连接。
* 注意：USB Type C 充电线的公端必须要有10mm。

| | | |
|---|---|---|
| 💡 | 0~25% | 蓝灯闪烁 |
| | 25~50% | 蓝灯常亮 |
| | 50~90% | 白灯闪烁 |
| | 90~100% | 白灯常亮 |

03

### 开机 / 关机

打开充电盒时，耳机会自动开机。
将耳机放回充电盒并合上盒盖，耳机将自动关机。

ON　　　　OFF

· 要手动打开耳机，请长按 MFS 按钮 3 秒钟。
· 要手动关闭耳机，请长按 MFS 按钮 7 秒钟。
两侧耳机都会自动断电。

04

---

### 佩戴

1. 选择适合您耳朵的耳塞尺寸，然后将其滑到耳机顶端。
2. 将耳机插入耳道并调整至舒适的位置，确保耳塞紧贴合。

05

### 配对/取消配对程序

使用前，Noble FoKus Triumph 需要与您的设备配对。配对后，每次激活它们都会自动连接。

#### 配对
1. 打开充电盒盖子。耳机将自动开机并进入配对模式，蓝色指示灯闪烁。
2. 在智能手机上启用蓝牙并在可用的蓝牙设备中搜索 "Noble FoKus Triumph"。找到后，选择 "Noble FoKus Triumph" 开始配对。你会听到"Connected"，耳机就可以使用了。

#### 配对新设备
1. 打开充电盒的盖子。耳机将自动开机并连接到您当前的设备。
2. 通过从智能手机的蓝牙设备列表中 "断开连接" 或删除 "Noble FoKus Triumph" 来取消将耳机与上次连接的智能手机的配对。
3. 断开连接后，耳机将自动进入配对模式，蓝色指示灯交替闪烁。
4. 在新设备上启用蓝牙，并在可用的蓝牙设备中搜索 "Noble FoKus Triumph"。找到后，选择 "Noble FoKus Triumph" 开始配对。你会听到"Connected"，耳机就可以使用了。

06

---

### 控制

| | | |
|---|---|---|
| ▶❙❙ | 播放/暂停 | 单击 MFS (L/R) |
| ◀+ | 提高音量+ | 三击 MFS (L) |
| ◀- | 音量减小- | 双击 MFS (R) |
| ❙◀ | 上一曲 | 双击 MFS (R) |
| ▶❙ | 下一曲 | 三击 MFS (R) |
| ☎/❌ | 接听/挂断电话 | 单击 MFS (L/R) |
| ☎ | 拒接来电 | 长按 MFS 2秒 (L/R) |
| 🎤 | 语音助手功能 - Siri / Google | 长按 MFS 3秒 (R) |
| 🔊 | 环境模式 | 长按 MFS 3 秒 (L) |

07

### LED指示灯

| 使用场景 | LED指示灯状态 |
|---|---|
| 开机 | 蓝色 LED 灯闪烁一秒钟 |
| 关机 | 蓝色 LED 灯闪烁一秒钟 |
| 配对 | 蓝色 LED 灯闪烁 |
| 配对成功 | 蓝色 LED 灯每 7 秒闪烁一次 |
| 播放音乐或通话 | LED 灯关闭 |
| 耳机电量低 | 蓝色 LED 灯每 8 秒闪烁两次 |
| 将耳机放入充电盒中 | 蓝色 LED 灯常亮 |
| 耳机放入充电盒满电后 | LED 灯关闭 |
| 充电盒充电中 | 0~25% 蓝灯闪烁 25~50% 蓝灯常亮 50~90% 白灯闪烁 90~100% 白灯常亮 |
| 充电盒满电后 | 白色 LED 灯常亮 |

· 单声道模式：蓝牙成功连接后，只要把任意一只耳机放回充电盒并合上盖子，另一只耳机将独立工作。
· 开机并连接后，如果任一只耳机电量耗尽并关机，另一只耳机可继续使用。
· 超距离回连：当耳机超出手机连接范围时，3分钟内回到有效距离会自动回连到手机；若超时 3 分钟未回连接，耳机将自动关机。

08

---

### 环境模式　在待机模式或播放音乐时

开启环境模式　　　　长按 3 秒

长按左耳塞触摸传感器3秒，语音提示 "Ambient Mode On"，将激活外部声音捕捉功能。

关闭环境模式　　　　长按 3 秒

长按左耳塞触摸传感器 3 秒钟，语音提示 "Ambient Mode Off"。

简而言之，这是 "Ambient Mode On" 和 "Ambient Mode Off" 的切换，长按左耳塞 3 秒。

长按3秒

09

### 重置程序

* 如果耳机无法相互配对或者无法与其他设备配对，请重置耳机。
1. 将耳机放回充电盒中
2. 按下复位按键5秒,直到两个耳机上的蓝色 LED 灯快速闪烁,重置完成,所有先前配对的设备都将被清除。
如果不小心只重置了一只耳机,则需要重置两只耳机才能再次作为一对耳机使用。

10

---

### 产品规格

| | |
|---|---|
| 产品型号 | Noble FoKus Triumph |
| 蓝牙版本 | V 5.3 |
| 支持协议 | A2DP、AVRCP、HFP、HSP |
| 音频传输 | SBC、AAC、Aptx Adaptive、Qss |
| 驱动单元 | Φ6.5mm 20Ω±4.5(15%) |
| 频率响应 | 20HZ～20KHZ |
| 连接距离 | ≥10m |
| 耳机电池容量(单个) | 45mAh |
| 充电保护盒电池容量 | 400mAh |
| 播放时间(因音量和内容而异) | 7H (50%音量)，通话时间4H |
| 充电时间 | 耳机:1.5小时; 充电盒:2小时 |
| 充电接口类型 | Type C |
| 电源输入 | 5V ⎓ 1A |

11

### 声明和警告
在配对新设备之前请断开当前设备。

#### ⚠ 警告!

长期暴露在高噪音环境中可能会导致永久性听力损伤。
请勿在嘈杂或明亮的场所使用 Noble FoKus Triumph 耳机。
如果您有心脏起搏器或其他电子医疗设备,请在使用您 Noble FoKus Triumph 耳机前咨询您的医生。
此包装包含小零件,可能对小孩造成危险。
请勿拆卸您的 Noble FoKus Triumph,因为它包含锂电池,拆卸可能会导致触电、火灾或人身伤害的危险。
避免电过高或过低造成电池损坏。
任何未经授权的人员拆卸更换或维修 Noble FoKus Triumph,都会导致 Noble FoKus Triumph 的保修失效。
本产品不适用于在水中或过于潮湿的环境中使用,请勿放入或浸没在水或其它液体中。否则将导致任何保修失效,并可能对产品造成永久性损坏。

12

---

---

# English Version



**NOBLE**

www.nobleaudio.com
https://www.facebook.com/NobleAudio
https://www.instagram.com/nobleaudio/
https://twitter.com/noblebywizard

图 217-241235

## FoKus Triumph
TRUE WIRELESS STEREO EARPHONE
INSTRUCTION MANUAL

---

### Packing List

Charging Case x1　　Earphones　　Charging Cable x1

Ear Tips x6　　Instruction Manual x1　　Storage Bag x1

01

### Overview

Multifunction Sensor (MFS)

Reset Button

Microphone

LED Light Indicators

LED Light Indicators

USB Type C Charging Port

02

---

### Charging

❶ Notes:
Please make sure the earphones and charging case are fully charged prior to first use.
The earphones and charging case need to be clean and dry before and during the charging process.

Charging Steps:
1. The earphones will power off automatically when put back in the charging case and the charging lid is closed.
The LED light will indicate the power capacity when lid is opened or closed.
2. Connect the charging case with power source by inserting the USB Type C charging cable.
* Note that the USB Type C cable must have a 10mm male termination.

| | | |
|---|---|---|
| 💡 | 0~25% | Blue LED light flashes |
| | 25~50% | Blue LED light on |
| | 50~90% | White LED light flashes |
| | 90~100% | White LED light on |

03

### Power On / Off

The earphones will power on automatically when charging lid is opened.
The earphones will power off automatically when put back in the charging case and the charging lid is closed.

ON　　　　OFF

To manually turn the earphones on, hold the MFS button for 3 seconds.
To manually turn off the earphones, hold the MFS button for 7 seconds. Both sides will power off automatically.

04

---

### Fit

1. Select an ear tip size suitable for your ear and slide them on to the tip of the earphone.
2. Insert the earphones into your ear canals and adjust them to a comfortable fit. Be sure that the eartips have a secure seal.

05

### Pairing/Unpairing Procedure

The Noble FoKus Triumph will need to be paired to your device before use. Once paired, they will connect automatically each time they are activated.

#### Pairing
1. Open the lid of the charging case.
The earphones will power on automatically and enter pairing mode, Blue LED light flashes.
2. Enable Bluetooth on your smartphone and search for "Noble FoKus Triumph" in available Bluetooth devices. Once found, select "Noble FoKus Triumph" to initiate pairing. You will hear "connected", now the earphones are ready for use.

#### Pairing a new device
1. Open the lid of your charging case. The earphones will power on automatically and connect to your current device.
2. To unpair the earphones from your last connected smartphone by "disconnecting" or deleting "Noble FoKus Triumph" from your smartphone's Bluetooth device list.
3. Once disconnected, the earphones will automatically enter pairing mode, with blue and white indicator lights flashing alternatively.
4. Enable Bluetooth on your new device, and search for "Noble FoKus Triumph" in the available Bluetooth devices. Once found, select "Noble FoKus Triumph" to initiate pairing. You will hear "connected", now the earphones are ready for use.

06

---

### Operation

| | | |
|---|---|---|
| ▶❙❙ | Play/Pause | Single Click MFS (L/R) |
| ◀+ | Volume Up+ | Triple Click MFS (L) |
| ◀- | Volume Down- | Double Click MFS (L) |
| ❙◀ | Previous Track | Double Click MFS (R) |
| ▶❙ | Next Track | Triple Click MFS (R) |
| ☎/❌ | Answer Call/Hang Up | Single Click MFS (L/R) |
| ☎ | Reject Call | Press the MFS for 2 seconds (L/R) |
| 🎤 | Voice Assistant function- Siri / Google | Press the MFS for 3 seconds (R) |
| 🔊 | Ambient mode | Press the MFS for 3 seconds (L) |

07

### LED Indicator Lights

| Usage Scenario | LED Indicator Status |
|---|---|
| Power On | Blue LED light flashes for one second |
| Power Off | Blue LED light flashes for one second |
| Pairing | Blue LED light flashes |
| Pairing succeeds | Blue LED light flashes every 7 seconds |
| Playing music or on calling | LED light off |
| Low Power | Blue LED light flashes twice every 8 seconds |
| When put earphones in the charger case | Blue LED light on |
| Earphones are sitted in the charger case | LED light off |
| Case is charging | 0~25% Blue LED light flashes / 25~50% Blue LED light on / 50~90% White LED light flashes / 90~100% White LED light on |
| Case full charged | White LED light on |

Single Pairing mode: Put one side back in the charging case and the other earphone will work independently.
One side will continue working even when the other side is powered off.
Pairing after being taken out of range: The earphones will automatically pair to the smartphone within 3 minutes if they are close to the smartphone again after being taken out of range. If they are not brought within range within three minutes, the headphones will automatically power off.

08

---

### Ambient Mode　In standby mode or when playing music

Ambient Mode On　　　Press and hold for 3 secs

Press and hold the left earbud touch sensor for 3 seconds with voice prompt "Ambient Mode On", it will activate the external sound capturing function.

Ambient Mode Off　　　Press and hold for 3 secs

Press and hold the left earbud touch sensor for 3 seconds with voice prompt "Ambient Mode Off".

The ambient mode can be turned off and on by pressing the LEFT earbud for 3 seconds.

Press and hold for 3 secs

09

### Reset Procedure

* If the earphones cannot pair to each other or to your bluetooth devices, please reset them.
1. Put both earphones into the charging case
2. Hold the reset button for 5 seconds until the blue LED lights on both earphones flash quickly. All previously paired devices will be cleared.The reset process is completed.
In the case that only one earphone is accidently reset, both earphones will need to be reset to function as a pair again.

10

---

### Specification

| | |
|---|---|
| Product Model | Noble FoKus Triumph |
| Bluetooth Version | V 5.3 |
| Bluetooth Profile | A2DP、AVRCP、HFP、HSP |
| Audio Codec | SBC、AAC、Aptx Adaptive、Qss |
| Driver size | Φ6.5mm 20Ω±4.5(15%) |
| Frequency response | 20HZ～20KHZ |
| Connection Distance | ≥10m |
| Earphone Battery Capacity | 45mAh |
| Charging Case Battery Capacity | 400mAh |
| Play time | 7H (50% volume), Talk time: 4H |
| Charging time | Earbuds: 1.5 hours; charger case: 2 hours |
| Charging Port | Type C |
| Power input | 5V ⎓ 1A |

11

### Declarations and Warnings
Disconnect previous devices before pairing a new device.

#### ⚠ WARNING!

Long-term exposure to high noise volumes may cause permanent hearing loss.
Do not use the Noble FoKus Triumph earphones in locations prohibiting the use of electronic equipment.
Consult your physician prior to using your Noble FoKus Triumph earphones if you have a pacemaker or other electrical medical devices.
This package contains small parts, which may pose a hazard to small children.
Do not disassemble the Noble FoKus Triumph as it contains lithium batteries, and disassembly could result in electric shock or fire or serious injury.
Any disassembly of the Noble FoKus Triumph, or attempt to replace or repair the Noble FoKus Triumph by an unauthorized person, will void the Noble FoKus Triumph warranty.
This product is not designed for use in water or wet environments. Keep product away from water and liquids.
Failure to do so will void any warranty and may cause permanent damage to the product.

12

---